



River Rock

The weathered contours of water-worn rocks are the inspiration for this mottled, textural paint collection. The subdued, natural tones of this unique finish are versatile enough for both sleek and rustic surroundings.

RLHOME.POLO.COM

Discover paint how-to videos and explore Ralph Lauren premium-quality latex paint in our entire spectrum of colors online or call **1-800-379-POLO** for questions.

Visit our comprehensive color display and obtain paint chips for accurate color & finish.

River Rock

To achieve the elegant look of this unique finish, please follow these simple steps. It will take two coats to achieve the River Rock look.

RALPH LAUREN PAINT NEEDED:



RALPH LAUREN OUT-OF-THE-CAN RIVER ROCK TEXTURED FINISH
A typical 12' x 12' room with an 8' ceiling will require approximately four (4) gallons. If ceiling heights are greater than 10ft., please seek the advice of a Ralph Lauren Professionally Certified Painter.

RALPH LAUREN APPLICATORS NEEDED:



9" UNIQUE FINISH ROLLER
Handle sold separately



4" UNIQUE FINISH TRIM ROLLER

- 3" Nylon/Poly Trim Brush
- Low-tack painter's tape

TAPING:

Tape around the ceiling and trim work before applying River Rock.

STEP 1:

FIRST COAT: ROLL

Fully saturate both the 4" and 9" unique finish rollers with River Rock before starting to apply River Rock to your wall. Starting at the top corner of the wall, cut in at the ceiling and corner with a brush,

Remove any brush lines from the wet paint by random rolling a pre-saturated Ralph Lauren Paint 4" unique finish roller over the cut in. *Helpful Hint:* Cut in smaller sections of the wall to ensure paint stays wet for blending.



STEP 2:

Continue across the wall; random rolling using the Ralph Lauren 9" unique finish roller. Roll on River Rock with a fully saturated and heavily loaded roller. A generous application of product is recommended. *Helpful Hint:* A typical roller load will cover a 1-1/2' x 1-1/2' area. Continue to apply River Rock down the wall to the baseboard, reloading the roller after each section.



Repeat this process across the entire wall. The first coat will appear uneven. Two coats are required for complete coverage. Allow paint to dry at least four hours before applying second coat.

STEP 3:

SECOND COAT:

Repeat step 1 & 2 continuing the random rolling motion across the wall. *Helpful Hint:* To achieve optimal results, apply generous amounts of River Rock to your wall.

TAPE REMOVAL:

Allow River Rock to dry overnight before removing tape.

Not recommended for application on ceilings or textured walls. River Rock is best suited for low traffic rooms.

RE-PAINTING YOUR WALLS

If, in the future, you wish to paint over the River Rock Finish, you do not need to sand your walls. Simply apply a coat of a premium primer and apply your new Ralph Lauren 100% Acrylic Latex Paint or new finish.

