

# GENERAL PAINTING

## Step By Step Instructions

### Getting Started:

- Fill a tray with paint.

### Border:

- Use a small trim brush to brush an even border along all edges, including the ceiling, floor and any moldings.
- You will also want to paint an even border on the edges of each corner. This will allow you to paint evenly where the roller will not be able to reach.

### Painting:

- Soak a 9" roller in the well of the paint tray. Work the roller over the ridged area to smooth the paint.
- Apply the paint to the wall using a "V" technique.
- Paint a large "V" on the wall. Spread the paint outward from the "V".
- Once a significant amount of paint is on the wall, spread horizontally and vertically.
- Once you have finished a section, complete the section with a continuous vertical sweeps of the wall.
- Sweep the roller from the top to bottom without re-loading with paint. This will smooth the coating and eliminate any roller marks.

### Helpful Hints:

- Wipe spills while still wet with a damp rag.
- Clean brushes and applicators while still wet with water.

